



ULD Control Quick Reference

Updated: 5/01/17

ALP				ALP Macro				AAZ			
Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H
L11	355	253	125 x 60.4 x 64	L11	448/403	253	125 x 60.4 x 64	L9N	470	365	125 x 88 x 64
Notes: MD11 P7-P13 & 747 lower deck				Notes: 106" Wide Dr/44" Pkg Dr				Notes: All Pos on all aircraft except MD11 P7-P13			
AAP				AMP Macro				AMP Wide Door			
Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H
L9O	487	379	125 x 88 x 64	AMP	509	418	125 x 96 x 64	AMP	566	418	125 x 96 x 64
Notes: 747, 767, A300, MD11 lower deck				Notes: Pkg Door - Intl Routes, lower deck				Notes: 106" Wide Door-Intl Routes, lower deck			
AAY (Standard)				AAY Open Front				AAD (Standard)			
Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H
A2N	480	420	125 x 88 x 81	A2O	524	420	125 x 88 x 81	A1	558	507	125 x 88 x 96
Notes: All main deck positions on all aircrafts				Notes: All main deck positions on all aircrafts				Notes: 767, A300, MD11 & 747			
AAD Open Front				AAD Macro				AAD Wide Door			
Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H
A1O	565	507	125 x 88 x 96	A1	516	507	125 x 88 x 96	A1W	545	507	125 x 88 x 96
Notes: 767, A300, MD11 & 747				Notes: Pkg Door 767, A300, MD11 & 747				Notes: 106" Wide Door 767, A300, MD11 & 747			

AAX				AMJ (Standard)				AMJ 3 Door			
Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H
A10	575	472	125 x 88 x 93	M1N	633	607	125 x 96 x 96	M1N	993	596	125 x 96 x 96
Notes:	767, A300, MD11 & 747			Notes:	747, MD11, Centerload 767			Notes:	747, MD11, Centerload 767		
AMJ Macro				AMJ Wide Door				AMX			
Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H
M1N	585	594	125 x 96 x 96	M1W	630	594	125 x 96 x 96	AMX	912	601	125 x 96 x 96
Notes:	Pkg Door-747, MD11s, 767 CL			Notes:	106" Wide Dr - 747, MD11s, 767 CL			Notes:	747, MD11s, Centerload 767		
AFA				AMD				PAG			
Type	Tare	Cube	Dims: L x W x H	Type	Tare	Cube	Dims: L x W x H	Type	Tare	Dims: L x W	
AFA	960	620	125 x 96 x 96	M1H	686	748	125 x 96 x 118	PA2	229	125 x 88	
Notes:	747 and centerload MD11 & 767			Notes:	747 Only door width 80"			Notes:	Non-reinforced pallet base		
PAH				PMC				PGE/PGA			
Type	Tare	Dims: L x W									
PA2	260	125 x 88									
Notes:	Reinforced pallet base for heavy shipments										
Type	Tare	Dims: L x W									
PM1	243	125 x 96									
Notes:	747, 767, A300 and MD11 except P7-P13										
Type	Tare	Dims: L x W									
PM2	1287	240 x 96									
Notes:	747 Aircraft Only										
PHP				FCC (Folded)				FCC (Deployed)			
Type	Tare	Dims: L x W x H									
P360	1200	80 x 52.5 x 58.5									
Notes:	SCS Pharmaceutical Shipments										
Type	Tare	Dims: L x W x H									
FCC	112	N/A									
Notes:	Targeted Intl Cargo Shipments										
Type	Tare	Dims: L x W x H									
FCC	112	N/A									
Notes:	A or M pallet bases up to 118" high										